# IC-2025

2 METER BAND SSB TRANSCEIVER

INSTRUCTION MANUAL

# TABLE OF CONTENTS

1.	Introduction
11.	Specifications
111.	Accessories
IV.	Pre-Operation
V.	Description of Controls and Connections
VI.	Operation
VII.	Theory
VIII.	Maintenance and Adjustment
IX.	Inside View
X.	Block Diagram
	Parts List
XII.	Board Layout
XIII.	Voltage Chart
XIV.	Options

#### SECTION I INTRODUCTION

Congratulations on the purchase of the IC-202S portable 2 meter SSB transceiver. The IC-202S was designed to be operable anywhere like most portables, but we also included features found in most base sets like a very effective noise blanker, RIT, S&RF meter, CW monitor, and a full 3 watts output on either USB or LSB. Two built-in crystals in the stable VXO allow operation between 144.00 and 144.40MHz. If you wish to expand the range of the IC-202S, we have also provided 2 spare crystal sockets for your convenience. With a slight retuning of the IC-202S, and installation of a special crystal, you may also work through OSCAR in USB for up-link (for mode A of AMSAT OSCAR 7 and 8, and for mode J of AMSAT OSCAR 8) and in LSB for down-link (for mode B of AMSAT OSCAR 7).



The aluminum die cast frame provides a very strong yet light housing for the 2 circuit boards, and the aluminum sides snap off easily if service is ever necessary or to change batteries.

The IC-202S operates on 9 inexpensive C cell batteries, or an external 13.8V DC source. The IC-202S will also operate on nicad batteries, contained in the BC-20/BC-15 nicad battery/charger kit. For AC operation, we recommend the IC-3PS which not only provides power for the IC-202S, but also doubles as a stand and holder for the IC-20L 10 watt linear amplifier.

You can use the built-in whip antenna for portable use, or a flexible antenna such as the IC-FA1. An external antenna connects to the antenna connector on the back of the IC-202S.

We are sure that you will have years of lasting enjoyment from your IC-202S, manufactured by the leader in communication equipment: Inoue Communication Equipment Corporation.

#### SECTION II SPECIFICATIONS

General:

Number of Semi-conductors Transistors 19

FET 7
IC 7
Diodes 36

Frequency Coverage 144—146MHz

Frequency Stability Less than 200Hz per hour at +25°C

Antenna Impedance 50 ohms unbalanced

Power Supply Requirements DC 13.8V±15% Negative Ground 800mA max

Current Drain Transmitting: A3J Approx. 540mA

Al Approx. 750mA

Receiving: At max audio approx 250mA

With no signal approx 90mA

Dial Light: Approx 40mA

Dimensions 183mm (H) x 61mm (W) x 162mm (D)

Net Weight 2.0kg including batteries.

Transmitter:

Emission Mode A3J (USB, LSB) and A1

RF Power Output A3J 3W (PEP)

A1 3W

Carrier Suppression More than 40dB below peak power

Unwanted Sideband Suppression More than 40dB down at 1000Hz AF input

Spurious Radiation More than 60dB below peak power

Microphone Impedance: 600 ohms

Input level: 10mV typical

Dynamic or optional Electret condenser microphone
CW Monitor
Built-in. Audio level adjustable by VOL knob.

\_\_\_\_\_\_

Receiver:
Receiving System Single Conversion Superheterodyne

Intermediate Frequency 10.7MHz

Receiving Mode A3J (USB, LSB) and A1

Spurious Response Rejection Ratio More than 60dB

Sensitivity Less than  $0.5\mu V$  for 10dB S+N/N

Selectivity  $\pm 1.2 \text{KHz at } -6 \text{dB}$ 

±2.4KHz at -60dB


Audio Output More than 1W

Audio Output Impedance 8 ohms

144.00—144.40MHz built-in (2 crystals). Each crystal gives 200KHz continuous coverage. Two spare crystal sockets are provided for additional frequency ranges between 144.40—146.00MHz.

# SECTION III ACCESSORIES

Various accessories are packed with your transceiver. Be sure not to overlook anything. Also it's a good idea to keep packing cartons in case of moving or if return for service is necessary.




1


1


1


- 1. Dynamic Microphone
- 2. Microphone Case
- 3. Shoulder Strap
- 4. Power Cord


- 5. Ext. Speaker Plug, Key Plug
- 6. Earphone 1
- 7. Dry Cells Type "C" 9
  - 8. Battery Tubes 3












#### SECTION IV PRE-OPERATION

#### **BATTERY INSTALLATION**

Dry Batteries:

Place the mode switch in the OFF position. Remove the side that covers the battery case and speaker. Install the batteries into the battery tubes (three in each) taking care to observe the same direction (polarity).

Carefully install the battery tubes in the manner shown in photograph 1, placing the last three batteries in the inner column. Again take care to observe polarity, and place the battery tubes on top of the ribbon so when the batteries need to be removed, a simple pull on the ribbon will make removal easier. With the batteries properly in place, carefully replace the side cover.



Nickel-Cadmium Batteries and Charger: BC-20

First, install the charger in the battery case (the speaker side) of the transceiver housing as shown in photograph 2. The polarity of the switch end of the charger must be positive and on the case side, negative. Accordingly the negative polarity must be connected to the spring side of the battery case.

Next, install five nickel-cadmium batteries in the battery tubes in the same direction. Make certain the (-) minus side is next to the spring. After installation of the charger and batteries in the case, connect the connector from the transceiver housing to the socket of the charger. Make sure the switch of the charger is ON, then install the side cover as before.


#### **AC BATTERY CHARGER: BC-15**

The BC-15 consists of an 117/220 Volt AC charger, 10 900mAh nickel-cadmium batteries, and a fuse box.

To install the BC-15 in the IC-202S, first put the Fuse Box into position, and then install the nickel-cadmium batteries in accordance with Photograph 3. After installation is completed, connect the output plug of the AC Adaptor to the External Power Supply Jack on the back of the IC-202S. For recharging, refer to the manual instructions for the AC adaptor.

After charging is completed, the batteries can be used in the same manner as dry cells. However, the voltage of nickel-cadmium batteries drops rapidly just before they are exhausted, so when the Power Indicator LED of the transceiver goes out, be sure to immediately stop using it, and charge the batteries again.

For use of the other sections, please refer to the charger instruction manual.



Photograph 3
Nickel-Cadmium Batteries
and Charger (BC-15) Installation

#### WHEN TO REPLACE BATTERIES

When the Power Indicator LED does not light up with the power switch ON, or when it lights up during reception and goes out during transmission, the batteries are exhausted. Use batteries of the same type, for mixed types might cause leakage. Replace worn batteries with a complete new set. If used with old batteries, the life of new ones might be shortened. Battery life is shortened more by transmitting than by receiving, since several times more current is drawn in transmit. To prolong battery life, therefore, practice as follows:

- \* Try to minimize the transmit period.
- \* Reduce volume during reception.
- \* Be sure to cut off power source when set is not used.

More working hours are available if high-performance batteries such as Alkaline type are employed.

#### EXTERNAL POWER PLUG CONNECTION

#### **External Power Source**

For use at home or in the car, please use the external power source which assures you of stable communication without concern about battery consumption.

- 1. Use either a regulated power supply or car battery of 13.8V DC and of over 1A current capability. (Though this transceiver may work at 11 to 15V DC, use it preferably at the rated voltage.)
- 2. Correctly connect the external supply as shown in the figure. If polarity is reversed, source power is cut off by the protection circuit and the unit will not operate.
- 3. When the transceiver is kept out of use for a prolonged period, the unit is operated for extended periods by external power only, or when the batteries are exhausted, etc., remove the batteries to protect the unit from possible damage by battery leakage.




#### FOR OUTDOOR USE

- 1. Insert the supplied batteries. (Refer to "BATTERY INSTALLATION")
- 2. Attach the supplied shoulder strap through the fixture of the body (as shown in the drawings on page 3).
- 3. Fully extend the whip antenna for operation, or install the flexible antenna. Keep the collapsible antenna depressed when the set is not in use so that it will not be damaged.


#### FOR USE IN THE CAR

- 1. Avoid using the unit near the outlet of heaters, air-conditioners, etc.
- 2. Install the unit in a convenient place to avoid disrupting safe driving.
- 3. For the best power source, connect to the car battery through a fuse (1A-2A).
- 4. Firmly ground to the car body a mobile antenna (e.g. whip antenna) that requires it.





#### Connection using IC-20L



#### FOR FIXED USE

- 1. Avoid installing the unit in places exposed to rain, water splash, direct sunshine, dust, vibration, or heat.
- 2. An external antenna should be used for indoor operation, The use of the whip or flexible antenna indoors may cause TVI, BCI, Hi-Fi interference, malfunction of stabilized DC power supply, etc. When using an external antenna, be sure to collapse the telescoping antenna into the body or remove the flexible antenna.
- 3. For fixed use, an external power supply is more economical than batteries.
- 4. Use of the linear amplifier IC-20L and AC power supply IC-3PS give excellent performance for fixed use.

#### HOW TO USE EXTERNAL ANTENNA

Select a high performance antenna (a multi-element beam or gain antenna) and set it up in the highest possible position. Tightly connect the antenna so that performance will not be affected by weather or vibration. The matching impedance is designed to be 50 ohms.


#### FOR SATELLITE COMMUNICATION USE

At present there are two active satellites for amateur radio use, AMSAT OSCAR 7 was launched in November, 1974 and AMSAT OSCAR 8 was launched in March, 1978. Satellite communications can be made by using an IC-202S for transmitting and an IC-701 (HF SSB/CW transceiver) for receiving in Mode A, and by using an IC-202S for receiving/transmitting and an IC-402 (70 cm SSB/CW transceiver) for transmitting/receiving in Mode B and Mode J. For frequency information refer to the chart below. Further information on communicating through satellites can be found in various amateur radio books and periodicals.

#### FREQUENCY CHART

SATELLITE	MODE	UPLINK (Transmitting) FREQUENCY	DOWNLINK (Receiving) FREQUENCY	BEACON
AMSAT	А	145.85MHz~145.95MHz (USB/CW)	29.4MHz~29.5MHz (USB/CW)	29,502MHz 435,100MHz
OSCAR 7 (AO-7)	В	432.125MHz~432.175MHz » (USB/CW)	. 145.975MHz~145.925MHz (LSB/CW)	145,972MHz
AMSAT OSCAR 8	А	145.85MHz~145.95MHz (USB/CW)	29.4MHz~29,5MHz (USB/CW)	29.402MHz
(AO-8)	J	145,90MHz~146,00MHz (USB/CW)	435,2MHz~435,1MHz (LSB/CW)	435,097MHz

### SECTION V DESCRIPTION OF CONTROLS AND CONNECTIONS



#### 1. POWER INDICATOR LED

Shows when power is applied to the IC-202S. (also indicates battery condition)

#### 2. S&RF METER

Indicates the relative signal strength of incoming signals and output power of transmitted signals.

#### 3. DIAL SCALE

The dial is divided into 10KHz increments with a total coverage of 200KHz. The operating frequency is read by adding the frequency shown on the dial to that shown on the crystal switch, or in the case of the spare crystals, by adding the dial reading to the lowest range frequency of the crystal installed. (see page 12.)

#### 4. TUNING KNOB

Tunes the frequency.

#### 5. RIT CONTROL

Independently swings the receiver frequency ±3KHz so that signals that are slightly off frequency may be tuned for clarity without affecting the transmitting frequency. For switching OFF the RIT to make the receiving and transmitting frequencies the same, turn the RIT control knob counterclockwise to the RIT OFF position.

#### 6. CW SWITCH

Be sure to set the MODE SWITCH at the USB position, or else your CW signal will not be transmitted. A CW MONITOR is built in, and the audio level can be adjusted with the VOLUME CONTROL.

#### 7. NOISE BLANKER SWITCH

In the NB position, the noise blanker is put into the circuit and noise pulses will be reduced.

#### 8. VOLUME CONTROL

Controls the audio output level. Controls the side-tone audio level in the CW transmit mode.

#### 9. CRYSTAL SWITCH

Selects the crystal to be used in the VXO, and therefore also selects the frequency range.

#### 10. MODE SWITCH

Selects a desired sideband (USB or LSB) in the MODE position. To turn on the meter light, set the switch to USB or LSB in the LIGHT position. The brightness of the light may be slightly dimmer in the USB mode than in the LSB mode. For CW operation, set at the USB mode.

#### 11. EXTERNAL SPEAKER JACK

An external speaker can be connected here. The impedance of the speaker should be 8 ohms. With the external speaker connected, the built-in speaker will be disabled.

#### 12. KEY JACK

Accepts a CW key for CW operation.

#### 13. MICROPHONE CONNECTOR

A 600 ohm microphone is connected here.

#### 14. SNAP LOCKS

Convenient snap-locks hold the sides in place. To remove them for any service or to replace the batteries, simply pull out on the center of the snap-locks and the cover can easily be removed. When replacing the covers be sure that you have placed the covers properly in the grooves provided, then push down on the center of the snap-lock (see page 4).

Note: when the sides are placed in the grooves, the snap-lock center must be pulled out.

#### 15. SHOULDER STRAP BRACKET

Connect the shoulder strap here for easy carrying (see page 3).

#### 16. WHIP ANTENNA

When not in use, the antenna should be fully collapsed. Extend completely for operation. Use care when expanding or compressing the antenna.

#### 17. FLEXIBLE ANTENNA (see page 31)

A flexible antenna, such as the IC-FA1, can be used. Unscrew the whip antenna from the set and install the flexible antenna in its place.

#### 18. MICROPHONE HANGER

When not in use, the mike can be hung out of the way.

#### 19. EXTERNAL ANTENNA CONNECTOR


Any well regulated power supply with an output of 13.8 volts can be connected here, instead of using the batteries installed. Inserting the power plug into the jack disables the internal battery source. When the BC-20 nicad battery pack is used, the external power source will charge the batteries.

#### 20. EXTERNAL ANTENNA RECEPTACLE

An external antenna of 50 ohms impedance can be connected here. If an external antenna is used, the built-in whip antenna should be completely collapsed or the flexible antenna should be disconnected.

#### 21. IDENTIFICATION PLATE


States model number and serial number.



#### SECTION VI OPERATION

- After the batteries have been installed, or the IC-202S is connected to an external
  power source, turn the MODE switch to the desired sideband in the MODE position. If the surrounding light is too dim to see the S&RF meter or frequency, turn
  the switch to the desired sideband in the LIGHT position, and the meter and dial
  will be illuminated.
- Extend the whip antenna its full length, or if you wish to use an external antenna, connect the cable to the EXTERNAL ANTENNA CONNECTOR on the back of the IC-202S.
- 3. Connect the microphone to the MICROPHONE CONNECTOR on the front panel.
- 4. If you wish to use the CW mode of transmission, connect a key to the KEY JACK on the front panel. You do not have to disconnect the microphone for CW operation.

#### Key Wiring Diagram



- 5. Place the CRYSTAL switch in the proper position for the portion of the 2 meter band you wish to operate in, whether it be CW or SSB. If you wish to operate outside of the 144.00–144.40MHz portion of the band, it will be necessary for you to install an additional crystal in one of the spare crystal sockets provided for this purpose. See page 12 for an explanation of how this is done. Crystals can be ordered from your authorized ICOM distributor or dealer.
- 6. Turn the tuning knob until you reach the desired frequency or a signal is heard. Adjust the volume control for a comfortable level of listening. You may wish to place the Noise Blanker switch in the NB position. This activates the noise blanking circuit which will suppress noise pulses. After selecting the operating frequency, if the received signal seems to drift, adjust the RIT control until the signal is again clear.
- 7. For SSB operation, hold the microphone close to your mouth, push the PTT switch on the microphone, and speak in a clear, normal tone of voice. For CW operation, after connecting your key and setting the MODE switch to the USB position, place the CW switch in the CW-T position and the IC-202S will transmit when the key contacts are closed. To receive, place the switch back in the REC position.

#### A/B POSITION SPARE CRYSTALS

The IC-202S comes with 2 crystals installed in the VXO for operation between 144.00—144.40MHz with each crystal covering 200KHz. If you wish to work another part of the

band, all that is needed is to install the proper frequency crystal in either the A or B spare crystal socket, tweak it, and you are ready for operation. Also a crystal can be installed to work the 145.80—146.00MHz portion of the band if you want to use OSCAR.

#### INSTRUCTIONS FOR INSTALLATION

Crystals 36-1 and 36-2 are already installed in the crystal sockets. These are for 144.00—144.20 (36-1) and 144.20—144.40MHz (36-2). Installing additional crystals in the spare crystal sockets in some positions and/or combinations may cause the output level of the operating crystal to decrease. This is due to absorption of some of the energy by the adjacent crystal.

BE SURE TO FOLLOW THE CHART EXACTLY AS TO POSITION AND COMBINATION OF THE SPARE CRYSTALS TO OBTAIN THE OPTIMUM PERFORMANCE.

	SPARE SOCKET	
	Α	В
OMBINATION OF	36–3	×
CRYSTALS	36-5	×
CHISTALS	36-6	×
	X	36-4
	X	36-5
	X	36-6
	36-3	36-4
	36-3	36-6
	36-5	36-4
	36-6	36-4

For combinations of crystals other than those listed, a slight modification or realignment will probably be required. For communication through OSCAR (145.80–146.00MHz) realignment of various parts besides the readjustment of the oscillator frequency will be necessary.

Xtal No.	Center Freq.	Range	Type	Actual Xtal Freq.
36-1	144.100MHz	144.000-144.200MHz	HC-18/U	14848.83KHz*
36-2	144.300	144.200-144.400	HC-18/U	14871.06*
36-3	144.500	144.400-144.600	HC-25/U	14893.28
36-4	144.700	144.600-144.800	HC-25/U	14915.50
36-5	144.900	144.800-145.000	HC-25/U	14937.72
36-6	145.900MHz	145.800-146.000MHz	HC-25/U	15048.83KHz**

- \* Supplied in the transceiver
- \*\* For OSCAR use.

Note: a. Crystal load capacitance is 20pF.

b. The frequency of the crystal unit (actual crystal frequency) does not correspond to the oscillation frequency in the circuit.

#### SECTION VII THEORY

#### **CIRCUITS**

Section X shows a block diagram of the IC-202S.

The receiving section is a single conversion superheterodyne, employing a wide band variable crystal oscillator (VXO) as the local oscillator. The transmitting section is a single conversion system which employs a filter-type SSB generator using a 10.7MHz crystal filter and the same local oscillator as the receiving section. A double-balanced mixer is used for the transmitting mixer to minimize spurious radiation. Although a portable unit, the IC-202S also features built-in circuits such as RIT, AGC, ALC, and a noise blanker.

#### RECEIVING CIRCUIT

The signal from the whip antenna or antenna terminal passes through the harmonic filter, through the T/R switching diode D26 (MO301), is amplified by RF amplifier Q2 (3SK40), and is then fed to the gate of mixer Q3 (2SK49). The switching diode D26 is turned ON with forward bias voltage by T/R control Q1 (2SA750), thus directing the input signal to Q2.

During transmission, the Receiver section +9V goes to zero to turn OFF Q1, and forward bias voltage is not applied to D26. At the same time, the transmit output is switched around Q2 to the antenna system. D26 is turned OFF as reverse bias is generated when the transmit signal is present. The 133MHz local oscillator output from the VXO is injected into mixer Q3 source through switching diode D28 (1SS53). The resultant conversion is an IF Frequency of 10.7NHz.

The IF signal passes through diode switch D1 (1SS53), which serves as both transmit-receive switch and noise blanker gate. IF selectivity is obtained by the 10.7MHz crystal filter, then the signal passes switching diode D3 (1SS53) and is amplified up to a suitable level by the IF amplifiers consisting of Q6 (3SK74-M), Q7 (3SK74-M) and IC1 (BA-401). The output of IC1 is applied to the demodulation and AGC circuits.

The detector circuit is a ring demodulator composed of D7 to D10 (1N60's) which uses the 10.6985MHz (USB), 10.7015MHz (LSB) from the BFO to generate the resultant audio signal. Higher audio frequencies of the demodulated signal are cut off by a low-pass filter consisting of C39, L11 and C40. The volume control (R-2) adjusts this output level which is fed to AF amplifier IC2 ( $\mu$ PC575C2) providing 1 watt of audio.

The network R32 and D11 (1S1555) provides positive bias to IC2 for muting audio during transmit and silent transmit-receive switching.

#### NOISE BLANKER

A part of the IF signal is picked up at the drain of mixer Q3, amplified by IC3 and IC4 (BA-401), and detected by D12 (1N60). This detected output is separated into signal audio components, and pulse components (noise). The signal component is amplified by Q4 (2SC945) and provides AGC control to IC3.

The noise pulse component turns ON Q5 (2SC945), and as long as noise exists, turns OFF noise blanker gate diode D1 by grounding its anode, thus the noise is not transferred to the crystal filter.

#### AGC CIRCUIT

A part of the IF signal is picked up from IF amplifier IC1 and passes through C76 and R57 to be detected by D15 (1N60), D16 and D17 (1S2473's). When no signal is received, bias voltage is applied to the base of AGC control Q10 (2SC945) through R56, D15 and D16, and the potential at the emitter of Q10 goes to nearly zero.

In the presence of a signal, C74 which is connected to Q10's base is first negatively charged because D16 is turned ON, and so Q10 is turned OFF. Also, C72 which is connected to Q10's emitter is negatively charged through D17 up to a voltage determined by the loop gain of each RF and IF amplifier, and C72 is kept at the achieved voltage due to the absence of a discharge circuit.

When the signal diminishes, the negative voltage charged in C75 is gradually discharged through R56 and drops down to a voltage where Q10 is turned ON. Then the negative voltage charged in C72 is rapidly discharged through Q10, thus the AGC time constant of fast attack and slow release is effected.

#### TRANSMITTING CIRCUIT

The small signal from the microphone is adjusted by the mike gain adjustment R17. Higher or lower frequencies outside desirable communication frequency range are attenuated by R68, C84 and C85, and the remaining frequencies are amplified by AF amplifier IC5 ( $\mu$ PC566H).

This AF signal and BFO output (10.6985MHz USB, 10.6995MHz CW, 10.7015MHz LSB) are fed to the balanced modulator IC6 (SN76514N). The resulting carrier suppressed double sideband signal is amplified by IF amplifier Q15 (2SK19). The unwanted side band is then removed by the 10.7MHz crystal filter where it passes through the diode switch D2 (1SS53) to become a 10.7MHz SSB signal.

This 10.7MHz signal passes the diode switch D4 (1SS53) to the transmit mixer IC7 (SN76514N). The 133MHz L.O. signal from the VXO unit is then combined to become an SSB signal of 144MHz. The transmit mixer IC7 is a double-balanced mixer, which minimizes spurious radiation.

In addition, the output circuits of IC7 and the 144MHz amplifier Q16 (3SK37) provides band-pass filtering which further minimizes spurious radiation. This 144MHz SSB signal is linearly amplified by Q17 (2SC383), Q18 (2SC2053), and Q19 (2SC1971) respectively. Higher harmonics are suppressed by the low-pass filter composed of L31, L32 and C148 to C152. The resultant output power is 3 Watts PEP. PA Q19 idling current is adjusted by R98. It is preset at 30mA.

#### ALC CIRCUIT

The ALC (Automatic Level Control) circuit picks out a part of the drive stage Q18 output, rectifies it by D23 (1S2473) and D24 (1N60), and applies the obtained negative voltage to the transmit IF amplifier Q15's gate to control circuit gain.

#### **CW TRANSMISSION**

For CW transmission, the voltage exerted on AF amplifier IC5 is reduced. At the same time the voltage to BFO frequency shift switch D13 (1SS53) is applied to turn it ON so that L15 is grounded as a part of the BFO crystal oscillator to shift the frequency about 1 KHz upward, which is within the crystal filter passband. Also, at the same time, the 5th Pin of the balanced modulator, IC6, is supplied with a voltage, which unbalances the modulator, so that the BFO frequency appears unsuppressed at the output. Consequently, these signals are amplified by the transmit IF amplifier Q15 and pass through the crystal filter, transmit mixer IC7 and forward as in the SSB mode. Keying is done at Q16's source and Q17's emitter. The 800Hz signal is oscillated by the CR phase oscillator Q3 (2SC945) for CW MONITOR and fed to the AF amplifier IC2 through the Volume Control.

# COMMON CIRCUITS BFO CIRCUIT

The BFO consists of a Colpitts crystal-oscillator Q8 (2SC945) and switching circuit D13 and D14. The crystal unit has only load capacitors C64 and 65 which are grounded through D14 and R46 in the LSB mode and operates at 10.7015MHz. In the USB mode, D14 is turned OFF, so that L15 and L16 are in series between C65 and the ground, and the circuit oscillates at 10.6985MHz. In CW transmit mode, D13 is turned ON and 10.6995MHz is oscillated with L16 and C65.

#### **METER CIRCUIT**

This circuit permits use of a single meter as an S-meter during reception and as an output level meter during transmission.

A bridge circuit composed of R53 and R54 is connected to the power source, stabilized by Zener diode D16 (WZ056), and the IF amplifier Q7 source. AGC voltage is generated by input signals reducing Q7's source voltage, thus unbalancing the bridge causing an upscale meter reading.

The S-meter is adjusted for its zero point by R53, and for its full scale point by R55.

For the output level meter, the output detection diode D27 (1N60) is coupled with L30 to partly rectify the RF output, thus giving an upscale relative output indication.

The extent of the meter indication can be adjusted by changing the degree of coupling of D27 and L30.

#### POWER SOURCE AND TRANSMIT/RECEIVE CHANGE-OVER CIRCUIT

The power source voltage (13.8V) is supplied from either the built-in batteries or external power source is connected to J10.

This voltage is directly applied to the AF power amplifier IC2 in the receiver section as well as to the collector of Q17, Q18 and Q19 in the power amplifier section.

Other circuits are fed with voltage from the voltage regulator circuits. The voltage regulator circuit for the VFO unit BFO and AGC circuits is derived from 13.8V to the Zener

diode D21 (XZ076) and POWER INDICATOR LED D-2 (light-emitting diode TLR-102), resulting in stabilized voltage of about 9.6V which becomes a reference level at D21's cathode. This voltage is applied to Q14's (2SC1209) base, and a regulated voltage of about 8.7V is available at its emitter.

The brightness of POWER INDICATOR LED varies according to the power voltage. When the power voltage drops to a level under about 10V, the current to D19 and D-2 stops, turning OFF D-2. Thus the power voltage fluctuation and battery condition can be judged from the D-2 Display. For the receiving section's regulated voltage supply the reference voltage of D19's cathode is applied to Q11's (2SD355) base through D18 (1S2473), and a regulated voltage of about 9.2V is obtained at its emitter.

When transmitting, R60 is grounded by the microphone PTT switch or CW switch (in the case of CW-T), to make Q11's base voltage zero and output voltage also zero.

Likewise, for the transmit section regulated voltage, the reference voltage of D19 cathode is applied to Q13's (2SD355) base through D19 (1S2473), and a regulated voltage of about 9.2V is obtained at its emitter.

During reception, since the PTT switch is not grounded, positive voltage is applied to the base of transmit/receive change-over control Q12 (2SC945) through R61 to turn it ON, while Q13's base is grounded through R62 and Q12, thus making the power voltage zero. When transmitting, the PTT switch is grounded and Q12's base is also grounded through D19 (1N60) to turn Q12 OFF and applies the reference voltage to Q13's base, and so a proper voltage is obtained. Also, the rise time for transmit/receive change-over is delayed by C11 and C78 respectively to prevent transmission signals from entering the receiving section during the change-over operation.

#### **VXO UNIT**

#### RIT CIRCUIT

During reception, when the RIT switch is turned ON, positive voltage is supplied to the base of Q1 (2SC945) through R1 and Q2's (2SC945) base through R4 to turn them ON. Varying the voltage supplied to D1 (MV201) by rotating the RIT control (R-1) varies the oscillating frequency of the VXO. When the RIT switch is in the OFF position or during transmission, both Q1 and Q2 are turned OFF and only the voltage divided by R2 and R3 is supplied, so that transmission can be made at dial-set frequencies irrespective of the position of RIT control. When the RIT is OFF, the receiving frequency is the same as the transmitting frequency.

#### **VXO CIRCUIT**

The oscillator Q4 (2SC1815), in series with a crystal and variable capacitor, varies its frequency by changing the capacity of the variable capacitor.

Resistors R13 to R16 are damping resistors to prevent abnormal oscillation. Capacitors C13 to C16 are linearity-adjusted for non-linearity frequency changes caused by any errors of the crystal unit and variable capacitor. L1 to L4 and C17 to C20 adjust the oscillation frequency and band width.

In this oscillator, a 14MHz signal is oscillated fundamentally, tripled by Q5 (2SC1815), tripled again by Q7 (2SC763) to a 133MHz signal with the level of 300mV as the first local oscillator. The band-pass filter composed of L7 to L9 minimizes spurious radiation.

Though the regulated voltage for the oscillator is supplied at a level of about 9 volts from Q14 of the main unit, it is further stabilized by the constant current circuit using Q6 (2SK19) and Zener diode D2 (WZ061). This voltage is supplied to Q4, Q5 and RIT circuit to further ensure sufficient frequency stability.

In the RIT circuit, the capacity of D1 is changed by voltage from R-1, RIT control, given through R17. C22 and C23 are connected in series, which keeps the RIT shift to approx. 2.5KHz.

#### SECTION VIII MAINTENANCE AND ADJUSTMENT

#### ADJUSTMENT OF VARIOUS SECTIONS

This set is completely adjusted and checked so that it functions correctly. During prolonged use, however, the preadjusted condition might be affected by wear of parts, etc. If it is necessary to make adjustments at some time to regain specified performance, the following procedures may be followed.


Remember that changes in capacitor or coils will be very small, if any. Adjustments should not be attempted without adequate test equipment.

#### VXO UNIT ADJUSTMENT

- 1. Measuring Instruments for Adjustment:
  - \* RF voltmeter (with over 1V full scale capability at 150MHz)
  - \* Frequency counter (capable of measuring 150MHz)
  - \* Multimeter (20Kohm per volt)
- 2. Frequency Adjustment:
  - a. Connect the frequency counter to No. 2 Pin of J7 of the VXO unit, with ground connected to No. 1 Pin of J7.
  - b. Place the RIT at the OFF position. Set the crystal switch to the position of the crystal to be aligned.
  - c. Set the tuning dial to "100", and adjust the appropriate coil until the frequency shown in the chart on page 18 is obtained.
  - d. Next set the dial to "200" and adjust trimmer (a) for the proper frequency according to the chart.
  - e. Set the dial now to "0" and adjust trimmer (b) for the proper frequency.
  - f. Repeat the adjustment above till no further adjustment is necessary to get the proper frequencies at all three points.

Court-I No		Dial	
Crystal No.	0	100	200
36-1	133.3015 MHz	133.4015 MHz	133.5015 MHz
36-2	133.5015	133.6015	133.7015
36-3	133.7015	133.8015	133.9015
36-4	133.9015	134.0015	134.1015
36-5	134.1015	134.2015	134.3015
36-6	135.1015	135.2015	135.3015

Note: Refer to page 12 for crystal data.



- 1. Crystal for 144.0MHz band
- 2. Coil for 144.0MHz band
- 3. Trimmer (a) for 144.0MHz band
- 4. Trimmer (b) for 144.0MHz band
- 5. Crystal for 144.2MHz band
- 6. Coil for 144.2MHz band
- 7. Trimmer (a) for 144.2MHz band
- 8. Trimmer (b) for 144.2MHz band
- 9. Additional Crystal Socket "A"
- 10. Coil for the "A" band
- 11. Trimmer (a) for the "A" band
- 12. Trimmer (b) for the "A" band
- 13. Additional Crystal Socket "B"
- 14. Coil for the "B" band
- 15. Trimmer (a) for the "B" band
- 16. Trimmer (b) for the "B" band

#### ADJUSTMENTS OF MULTIPLIER STAGES

For receiving, set the crystal selector to "144.2" and the tuning knob to the "200" position (the receiving frequency is 144.4MHz), connect a multimeter (3 volt range) to check point R27 and tune L5 and L6 for maximum indication. Connect the probe of an RF voltmeter to the output terminal J7 of VXO and tune L7  $\sim$  L9 for maximum indication. Further, readjust L5 and L6 and repeat this procedure to obtain the maximum indication on the RF voltmeter (250 - 300mV).

#### **RIT ADJUSTMENT**

In the receive mode connect the frequency counter to J7, set the RIT knob to the center and record the frequency (the dial scale may be set at any position but do not change it during the adjustment).

Next, turn the CW switch to "CW-T" without connecting the key to the key jack, then check the frequency again. If it differs from the previously recorded frequency, adjust R2 to equalize both frequencies.

Repeat above adjustments to reduce the frequency difference between reception and transmission to under 10Hz.

#### TRANSMITTING SECTION ADJUSTMENT

#### a. Measuring Instruments for Adjustment

- \* Terminal wattmeter (for about 10W full scale with 50 ohm impedance)
- \* Frequency counter
- \* RF voltmeter
- \* AF oscillator
- \* AF millivoltmeter
- \* Multimeter (20Kohm per volt)

#### b. Final Stage Idle Current Adjustment

Turn the CW switch to "CW-T" without connecting the key to the key jack. Remove the solder of C144 and W25, and connect the multimeter, which is set at 100mA range, between these points. Adjust R98 so that the current becomes 30mA. After the adjustment, resolder the leads of C144 and W25.

#### c. Coil Adjustment

Connect the wattmeter to the external antenna socket, and set the transmit/receive frequency at "144.4MHz". With the CW switch set to "CW-T", connect the key to the key jack and hold down the key. Connect the RF voltmeter probe to check point CP3 and adjust the cores of L18 to L21 alternately for a maximum voltmeter reading.

#### d. Driver and Final Stage Adjustments

Make sure that the power voltage is 13.8V under the same condition as in (c). Turn the R99 rotor toward ground (to panel face) and adjust C125, C126, C133, C134, C146 and C147 so that the wattmeter indicates maximum (over 3W). After this, adjust R99 so that the wattmeter indicates exactly 3W. Set the multimeter to the 1 volt range and connect to check point CP4. Readjust L18 to L21 for maximum indication.

#### e. RF Meter Adjustment

Move D27 with respect to L30 (coupling) so that the meter indicates about 90% of full scale when the output is 3W at the completion of adjustment (d).

#### f. Carrier Frequency Adjustment

When in receive and with the mode switch in the LSB position, connect a frequency counter to check point CP5 and adjust C64 for 10.7015MHz. Change the mode switch to the USB position, set the CW switch to the CW-T and adjust L16 for 10.6995MHz. Then set the CW switch to the REC position and adjust L15 for 10.6985MHz. Turn the MODE switch to LSB and connect the AF oscillator to check point, CP2. Ground the Microphone connector pin No. 2 for SSB transmission, and set the AF oscillator frequency at 1.5KHz. Adjust the RF output level to 2.0W. Keeping the output level of the 'AF oscillator unchanged, alternately change the audio oscillator frequency from 300Hz to 3KHz, and fine adjust C64 to balance the RF output.

Place the MODE switch to USB and adjust L15 the same as the adjustments done in LSB. Repeat adjustments in LSB and USB until no difference is present.

#### g. Mic Gain Adjustment

Connect the AF oscillator between the Microphone connector pins No.1 and No.4 (ground). Set its frequency at 1.5KHz and output level at 2mV.

Ground the Microphone connector pin No. 2 and connect the AF millivoltmeter (300mV range) to check point CP2 and adjust R67 so that the meter reads 100mV. This adjustment can be slightly changed according to the use of microphone, strength of voice, condition, etc. Observation of the output carrier on a high frequency oscilloscope would be helpful while using normal microphone procedures in order to achieve optimum waveform and quality.

#### RECEIVING SECTION ADJUSTMENT

#### a. Measuring Instruments for Adjustment

- \* Standard signal generator (for 144MHz band)
- \* AF millivoltmeter
- \* Multimeter

#### b. Sensitivity Adjustment

With the receiving frequency set at 144.4MHz and MODE switch in the LSB or USB position and the volume control knob set to a reasonable volume position, connect the standard signal generator to the external antenna connector and the AF millivoltmeter (1V range) to the AF output terminals J4 and J5 (ground).

(Never transmit during this adjustment because it may damage the signal generator attenuators.)

Keeping the signal generator unmodulated, set the output level at about 30dB ( $\mu V$ ) and adjust the generator frequency to the receiving frequency. As a beat is heard from the speaker, fine-adjust the signal generator frequency or receiving frequency

so that the beat becomes about 1000Hz. Try to keep the beat at this frequency during the adjustment.

Next, adjust L1-L10 cores successively to maximize the AF millivoltmeter indication, and if the AF millivoltmeter becomes full-scale, lower the signal generator output level without converting the meter range or turning the volume control knob, etc. Repeat the adjustment until the AF millivoltmeter indicates over 800 mV with the volume control knob at maximum and S+N/N becomes over 10 dB when the signal generator output level is -10 dB ( $\mu \text{V}$ ).


#### c. S-Meter Adjustment


Adjust R53 so that the S-meter indicates zero with no signal. Next, with the signal generator output level set at 90dB ( $\mu V$ ), adjust the frequency to the receiving frequency, and adjust R55 so that the S-meter indicates full scale. After this adjustment is finished, lower the signal generator output level, and make sure that the signal generator output is within a range of 0dB  $\pm$  3dB when the S-meter indicates S5.


#### d. Noise Blanker Adjustment

Set the signal generator output level at about 30dB ( $\mu$ V), and adjust to the receiving frequency. Making sure that the beat is generated from the speaker, connect the multimeter (0.3V range) to check point CP1, and gradually lower the signal generator output level and adjust L12 to a point where the indication is maximum.

# SECTION IX INSIDE VIEW







# SECTION XI PARTS LIST

	MAIN UNIT	
Ref. No.	Description	Part No.
Q1 Q2 Q3 Q4 Q5 Q6 Q7 Q8 Q9 Q10 Q11 Q12 Q13 Q14 Q15 Q16 Q17 Q18 Q19	Transistor FET FET Transistor FET FET Transistor FET FET Transistor Transistor	2SA750(1) 3SK40-M 2SK49-H2 2SC945-P 2SC945-P 3SK74-M 3SK74-M 2SC945-P 2SC945-P 2SC945-R 2SD355-E 2SC945-P 2SD355-E 2SC1209-E 2SK19-GR 3SK37-3 2SC383 2SC2053 2SC1971
IC1 IC2 IC3 IC4 IC5 IC6 IC7	IC IC IC IC IC IC	BA-401 μPC575C2 BA-401 BA-401 μPC566H SN76514N SN76514N
D1 D2 D3 D4 D5 D6 D7 D8 D9 D10 D11 D12 D13 D14 D15 D16 D17 D18 D19 D20 D21 D22 D23 D24 D25 D26	Diode	1SS53 1SS53 1SS53 1SS53 1N60 WZ056 1N60 1N60 1N60 1S1555 1N60 1SS53 1SS53 1N60 1S2473 1S2473 1S2473 1S2473 1S2473 1N60 1S2473

	MAIN UNIT			
Ref. No.	Description	Part No.		
D27 D28 D29 D30	Diode Diode Diode Diode	1N60 1SS53 1SS53 1SS53		
FL1 X1		FEC-103-1 10.7MHz C-18/U 10.7015MHz		
L1 L2 L3 L4 L5 L6 L7 L8 L9 L10 L11 L12 L13 L14 L15 L16 L17 L18 L19 L20 L21 L22 L23 L24 L25 L26 L27 L28 L29 L30 L31 L32 L33 L34	Coil Coil Coil Coil Coil Coil Coil Coil	LS-4 LS-3A LS-3A LS-7 LS-7 LS-66A LS-66A LS-66A LS-66A LS-68 RFC 104 (100mH) LS-7 RFC 101 (100µH) RFC 101 (100µH) LS-111 LS-111 RFC 101 (100µH) LS-3A LS-3A LS-3A LS-3A LS-3A LS-3A LS-3A LA-96 LA-71 LA-2 LA-9 LA-9 LA-9 LA-9 LA-71 RFC 100 (10µH) RFC 101 (100µH)		
R1 R2 R3 R4 R5 R6 R7 R8 R9 R10	Resistor	470 ohm ELR25 4.7K ohm ELR25 100K ohm ELR25 100K ohm ELR25 47 ohm ELR25 22 ohm ELR25 4.7K ohm ELR25 1K ohm ELR25 220 ohm ELR25 220 ohm ELR25		

	MAIN UNIT				
Ref.	No. Description	n Part No.			
R12 R13 R14 R15 R16 R17 R18 R19 R20 R21 R22 R23 R24 R25 R26 R27 R28 R30 R31 R32 R33 R34 R35 R36 R37 R38 R40 R41 R42 R43 R45 R45 R46 R47 R45 R46 R56 R57 R56 R57 R58 R56 R57 R56 R56 R57 R56 R57 R56 R61 R62 R63 R64 R65	Resistor	3.3K ohm 12K ohm 3.3K ohm 10K ohm 10K ohm 10K ohm 10K ohm 10K ohm 10K ohm 22K ohm 10OK ohm 22O ohm 6.8K ohm 470 ohm 22O ohm 470 ohm 470 ohm 470 ohm 470 ohm 470 ohm 47K ohm 150K ohm 150K ohm 10K ohm 12K ohm 10K ohm 12K ohm 10K ohm 10OK ohm 10K ohm 10OK ohm	ELR25		

	MAIN UNIT			
Ref. No.	Description	Part No.		
R66 R67 R68 R69 R70 R71 R72 R73 R74 R75 R76 R77 R78 R79 R80 R81 R82 R83 R84 R85 R86 R87 R88 R89 R90 R91 R92 R93 R94 R95 R96 R97 R98 R90 R100 R101 R102 R103 R104 R105 R106 R107 R108 R109 R110 R111 R112 R113 R114 C1 C2 C3	Resistor Trimmer Resistor	22 ohm 500 ohm 2.2K ohm 150K ohm 56K ohm 56K ohm 56K ohm 15K ohm 15K ohm 130 ohm 100 ohm 2.7K ohm 100 ohm 47 ohm 2.7K ohm 2.	ELR25 FR-10 ELR25 FR-10 FR-10 ELR25 FR-10 FR-10 ELR25	

	MAIN UNIT			
Ref. No.	Description	Part No.		
C4 C5 C6 C7 C8 C9 C10 C11 C12 C13 C14 C15 C16 C17 C18 C19 C20 C21 C22 C23 C24 C25 C26 C27 C28 C29 C30 C31 C32 C33 C34 C35 C36 C37 C38 C39 C40 C41 C42 C43 C44 C45 C46 C47 C48 C49 C50	Ceramic Electrolytic	Part No.  0.01µF 0.001µF 0.01µF 0.01µF 0.01µF 0.01µF 0.035pF 6pF 0.01µF 0.001µF 0.056µF	50V 50V 50V 50V 50V 50V 50V 50V 50V 50V	
C51 C52 C53 C54	Semi-con- ductive Ceramic Electrolytic Ceramic	0.2µF 0.0047µF 1µF 0.001µF	12V 50V 50V 50V	

	MAIN UNIT				
Ref. No.	Description	Part No.			
C55 C56 C57 C58 C59 C60 C61 C62 C63 C64 C65 C66 C67	Ceramic Trimmer Ceramic Ceramic Styrene	101	50V 50V C-1H- IJ) C-1H- IJ)		
C69 C70 C71 C72 C73 C74 C75 C76 C77 C78 C79 C80 C81 C82 C83 C84 C85 C86 C87 C88 C89 C90 C91 C92 C93 C94 C95 C96 C97 C98 C99 C100 C101 C102 C103 C104 C105	Ceramic Ceramic Electrolytic Ceramic Electrolytic Ceramic Electrolytic Electrolytic Electrolytic Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic Electrolytic Ceramic	0.0047µF 56pF 56pF 56pF 0.01µF	50V 50V 50V 50V 50V 50V 50V 50V		

NAA INI HINIT				
Description	Part No.			
Ceramic Trimmer Trimmer Telectrolytic Ceramic Electrolytic Ceramic Electrolytic Feed Through Ceramic	0.01µF 0.01µF 0.01µF 10µF 0.01µF 2pF 6pF 0.01µF 0.01µF 0.01µF 8pF 8pF 100pF 470pF 0.01µF 12pF (CV0 10µF 0.01µF 0.01µF 10µF 10µF 1	5D180) 16V 50V 50V 50V 50V 50V 50-11) 50V 50V 16V 50V 50V 16V 50V 16V 50V 50V 50V 50V 50V		
	Ceramic Electrolytic Ceramic Electrolytic Ceramic	Ceramic         0.01μF           Ceramic         0.01μF           Electrolytic         10μF           Ceramic         0.01μF           Ceramic         7pF           Ceramic         6pF           Ceramic         0.01μF           Ceramic         0.01μF <t< th=""></t<>		

VXO UNIT						
Ref. No.	Description	Part No.				
J1 J2 J3 J4 J5 J6 J7 J8	Connector Connector Connector Connector Connector Eyelet Eyelet	5041-08A 5041-08A 5041-02A 5041-02A 5041-02A 5041-02A 2x3 2x3				
Q1 Q2 Q3 Q4 Q5 Q6 Q7	Transistor Transistor Transistor Transistor Transistor FET Transistor	2SC945-P 2SC945-P 2SC945-P 2SC1815-Y 2SC1815-Y 2SK19-GR 2SC763-C				
D1 D2	Diode Diode	MV201 WZ061				
X1 X2	Xtal Xtal	36-1 HC-18/U 36-2 HC-18/U				
L1 L2 L3 L4 L5 L6 L7 L8	Coil Coil Coil Coil Coil Coil Coil Coil	LB-28B LB-28B LB-28B LS-2 LS-2 LS-3A LS-3A LS-3A				
R1 R2 R3 R4 R5 R6 R7 R8 R9 R10 R11 R12 R13 R14 R15 R16 R17 R18 R20 R21 R22 R23 R24 R25 R27 R28	Resistor Trimmer Resistor	100K ohm RGP102 33K ohm ELR25 10K ohm ELR25 10K ohm ELR25 2.2K ohm ELR25 4.7K ohm ELR25 1M ohm ELR25 22K ohm ELR25 22K ohm ELR25 100K ohm ELR25 100K ohm ELR25 100K ohm ELR25 100K ohm ELR25 220K ohm ELR25 220K ohm ELR25 22K ohm ELR25 22K ohm ELR25 20K ohm ELR25 330 ohm ELR25				

Ref. No.         Description         Part No.           C1         Ceramic         0.001μF         50V           C2         Ceramic         0.001μF         50V           C3         Ceramic         0.001μF         50V           C4         Ceramic         0.001μF         50V           C5         Ceramic         0.001μF         50V           C6         Ceramic         0.01μF         50V           C7         Mylar         0.01μF         50V           C8         Mylar         0.01μF         50V           C9         Mylar         0.01μF         50V           C10         Ceramic         470pF         50V           C11         Mylar         0.01μF         50V           C12         Mylar         0.01μF         50V           C13         Trimmer         5pF (CV05A050)           C15         Trimmer         5pF (CV05A050)           C15         Trimmer         12pF (CV05C120)           C17         Trimmer         12pF (CV05C120)           C17         Trimmer         12pF (CV05C120)           C19         Trimmer         12pF (CV05C120)           C21         Ceramic </th <th></th> <th colspan="5">VXO UNIT</th>		VXO UNIT				
C2         Ceramic         0.001 μF         50V           C3         Ceramic         0.001 μF         50V           C4         Ceramic         0.001 μF         50V           C5         Ceramic         0.001 μF         50V           C6         Ceramic         0.01 μF         50V           C7         Mylar         0.01 μF         50V           C8         Mylar         0.01 μF         50V           C9         Mylar         0.0033 μF         50V           C11         Mylar         0.0033 μF         50V           C12         Mylar         0.01 μF         50V           C13         Trimmer         5pF (CV05A050)           C14         Trimmer         5pF (CV05A050)           C15         Trimmer         12pF (CV05C120)           C16         Trimmer         12pF (CV05C120)           C17         Trimmer         12pF (CV05C120)           C18         Trimmer         12pF (CV05C120)           C19         Trimmer         12pF (CV05C120)           C21         Ceramic         0.01 μF         50V           C22         Ceramic         10pF (CH)         50V           C23	Ref. No.	Description	Part No.			
J1 Connector 5041-06A J2 Eyelet 2x3 J3 Eyelet 2x3 J4 Eyelet 2x3 J5 Eyelet 2x3 J6 Eyelet 2x3 J7 Connector 5041-02A  Xtal Socket 380-598-2	C2 C3 C4 C5 C6 C7 C8 C9 C10 C11 C12 C13 C14 C15 C16 C17 C18 C20 C21 C22 C23 C24 C25 C26 C27 C28 C29 C30 C31 C32 C34 C35 C36 C37 C38 C39 C40 C41 C42 C43 C44 C45	Ceramic Ceramic Ceramic Ceramic Ceramic Mylar Mylar Mylar Mylar Mylar Mylar Mylar Mylar Trimmer Trimmer Trimmer Trimmer Trimmer Trimmer Trimmer Ceramic	0.001 µF 50 V 0.01 µF 50 V 0.003 µF 50 V 0.003 µF 50 V 0.003 µF 50 V 0.01 µF 50 V 5pF (CV05A050) 5pF (CV05A050) 5pF (CV05A050) 12pF (CV05C120) 12pF (CV05C120) 12pF (CV05C120) 12pF (CV05C120) 12pF (CV05C120) 0.01 µF 50 V 10pF(CH) 50 V 33 µF 10 V 0.01 µF 50 V 0.01 µF 50 V 10pF(CH) 200pF(XL) 50 V 39pF(PH) 1 pF 50 V 47pF 50 V 47pF 50 V 0.01 µF 50 V 0.01 µF 50 V 0.01 µF 50 V 0.01 µF 50 V 47pF 50 V 0.01 µF 50 V			
	J2 J3 J4 J5 J6	Eyelet Eyelet Eyelet Eyelet Eyelet	2x3 2x3 2x3 2x3 2x3 2x3			
(CRYSTAL)	S1	Rotary switch				

FRONT PANEL AND FRAME							
Ref. No.	. Description	Part N	o.				
D1 D2 D3 D4 D5	Diode (LED) Diode Diode Diode Diode	TLR-10 1N60 1SS53 HFS-04 1N60					
L1 L2	Choke Coil Coil	RFC 10 LA-2	2(1mH)				
C1 C2 C3 C4 C5 C6	Electrolytic Ceramic Ceramic Electrolytic Electrolytic Variable	1000µF 0.001µF 0.001µF 4.7µF 10µF C321A	= 50V				
C7 C8 C9 C10	(TUNE) Ceramic Ceramic Ceramic Ceramic	47pF 0.001µF 0.001µF 0.01µF					
R1 R2 R3 R4 R5	Variable (RIT Variable (VOI Resistor Resistor Resistor	L) 10K o 22 ohr 4.7K o	m PR123S6515K hm PR-18-15K m R50 ohm R25 nm R25				
M1	Meter	YN30-1					
SP1	Speaker	6S03					
PL1	Lamp	BQ054-	322522A				
S1	Switch (CW	SLC-220	C				
SW) S2 Switch (NB SLC-22C		C					
S3	SW) Rotary switch ESR-E125K20Z (MODE SW)  Connector (ANT) MRB 4P Base (MIC) 4P-B 3P Connector (POWER) S-16942 Phone Jack (EXT SPK) SJ-296 Phone Jack (KEY) SJ-296						
J1 J2 J3 J4 J5							
P1 P2 P3 P4 P5 P6 P7 P8	Connector         5250-08N           Connector         5250-06N           Connector         5250-04N           Connector         5250-08N           Connector         5250-02N           Connector         5250-02N           Connector         5250-02N           Connector         5250-02N           Connector         5250-02N           Connector         5250-02N           Connector         5250-02N						
	PC Board PC Board Tuning Knob RIT Knob VOL Knob CRYSTAL SV MODE SW Kr		B-159 (LED) B-249 (MIC) N-16A (40811) N-33 (41408) N-33 (41408) N-32 (41407) N-32 (41407)				

#### SECTION XIV OPTIONS


We have prepared a variety of options for the portable transceiver IC-202S in order to enlarge its use as a portable, mobile and fixed set.




IC-20L LINEAR AMPLIFIER 144MHz 10W



POWER SUPPLY 13.8V 3A




IC-SM2
DESK MICROPHONE
ELECTRET CONDENSER
TYPE



RECHARGEABLE
BATTERY PACK
BATTERY CHARGER BC-20
BATTERY N-900 x 10
(900 mAh)




MOBILE MOUNTING BRACKET (B) FOR IC-202S




MOBILE MOUNTING KIT FOR IC-20L



RECHARGEABLE
BATTERY PACK
AC BATTERY CHARGER
BC-15
BATTERY N-900 C x 10
(900 mAh)



IC-FA1 FLEXIBLE ANTENNA



Printed in Japan Dec. 1979